

Reed Switch Connection, Sealing and Removal

Connecting the reed switch - push back the bayonet connector as shown below:



Insert the reed switch into the register:



Rotate the reed switch to the point where it goes further into the register:



Push down the bayonet and rotate it clockwise to lock the reed switch:



Sealing the reed switch – select a reed switch seal:



Insert the seal as shown below:



Push the seal down till it snaps in and locks:



The reed switch is now sealed:



Removing the reed switch – use a cutter to cut the connecting bridge between the peg and the latch:



Remove the peg:



Rotate the bayonet counterclockwise and pull out the reed switch:



Remove the latch:

